


	Equipment protected throughout by double insulation.
	Fuse must be replaced with ratings specified in the manual.
	AC (Alternating Current)
	DC (Direct Current)
CAT II	It is applicable to test and measuring circuits connected directly to utilization points (socket outlets and similar points) of the low-voltage MAINS installation.
CAT III	It is applicable to test and measuring circuits connected to the distribution part of the building's low-voltage MAINS installation.
	European union directives
	CONFORMS TO UL STD. 61010-1, 61010-2-030, 61010-2-033, 61010-031; CERTIFIED TO CSA STD. C22.2 No.61010-1,61010-2-030, 61010-2-033, 61010-031.

Maintenance

- Before opening case .always disconnect test leads from all energized circuits.
- For continuous protection against fire. Replace fuse only with ratings: F 200mA H 600V
- Never use the meter unless the back cover is in place and fastened completely.
- Do not use abrasives or solvents on the meter .to clean it use only a damp cloth and mild detergent.

Front panel



1. Range switch
This switch is used to select desired ranges as well as to turn on/off the meter .
2. Function switch
switch for selecting functions.
3. LCD display
3 1/2digit.7segment.maximum 1999 counts.
4. Test leads
Red test lead for positive (+) and black test lead for negative (-).

General description

This compact digital multimeter is designed to measure AC and DC voltages .DC current .Resistance . Diode and to perform audible continuity checks with accuracy and easy .

Small and lightweight .with a carrying case and test leads wound on its body. This instrument will provide you years of satisfactory service.

Specification

Accuracy is guaranteed for 1 year .
23°C ±5°C, Less than 75%RH.

DC Voltage

Range	Resolution	Accuracy
2V	1mV	±0.5% of rdg ±1dgt
20V	10mV	±0.8% of rdg ±1dgt
200mV	100mV	±0.8% of rdg ±1dgt
600V	1V	±0.8% of rdg ±1dgt

Overload protection: 600V dc or rms ac for all ranges

AC Voltage

Range	Resolution	Accuracy
200V	100mV	±1.2% of rdg ±10dgt
600V	1V	±1.2% of rdg ±10dgt

Overload protection: 600V dc or rms ac for all ranges
Frequency range: 45Hz to 450Hz
Response: average responding .calibrated in rms of a sine wave

DC Current

Range	Resolution	Accuracy
200mA	0.1mA	±2.0% of rdg ±2dgt

Overload protection: F200mA H 600V fuse

Resistance

Range	Resolution	Accuracy
2kΩ	1Ω	±1.0% of rdg ±2dgt
20kΩ	10Ω	±1.0% of rdg ±2dgt
200kΩ	100Ω	±1.0% of rdg ±2dgt
2000kΩ	1kΩ	±1.0% of rdg ±2dgt

Maximum open circuit voltage : 0.65V
overload protection: 600V rms ac for all ranges

Diode test

Range	Description
	Show the approx. forward voltage drop of the diode.

Overload protection: 600V rms ac

Diode test

Range	Description
	Built-in buzzer sounds when resistance is less than 50Ω.

Overload protection: 600V rms ac

General characteristics

Maximum voltage between Terminals and earth ground	CAT III 300V, CAT II 600V
Fuse protection	F 200mA H 600V
Power supply	12V battery .GP -23AX1
Display	LCD .1999 counts .updates 2-3/sec
Measuring method	dual-slope integration A/D converter
Over range indication	only figure "1" on the display
Polarity indication	" - " displayed for negative polarity
Operating temperature	0°C to 40°C (32°F to 104 °F)
Storage temperature	-10°C to 50°C (10°F to 122°F)
Low battery indication	 appears on the display
Size	120x70x18mm
Weight	approx.110g

Operating instruction

DC Voltage measurement

1. Set the function switch at V_{DC} position
2. Set the range switch at desired position. If the magnitude of voltage to be measured is unknown beforehand . set the range switch at the highest position and then reduce until satisfactory reading is obtained.
3. Connect test leads across the source or load being measured. The polarity of red lead connection will be indicated at the same time as the voltage value.
4. When the range switch is set at 600V position. "HV" sign will appear on the display to remind user of high voltage measurement. Special attention should be paid.

AC Voltage measurement

1. Set the function switch at V_{AC} position
2. Set the range switch at desired position .measurement reading can be obtained at 2V and 20V positions, but the accuracy is not guaranteed.
3. Connect test leads across the source or load being measured and read the voltage value on the LCD display.
4. When the range switch is set at 600V position , a "HV" sign will appear on the display to remind user of high voltage measurement.

DC Current measurement

1. Set the function switch at A_{DC} position.
2. Set the range switch at 200mA position .measurement reading can be obtained at other positions. But the decimal point will be at the incorrect place.
3. Open the circuit in which the current is to be measured. And connect test leads in series with the circuit.
4. Read current value on the LCD display along with the polarity of red lead connection.

Resistance measurement

1. Set the function switch at Ω position .(note: the polarity of red lead is positive "+")
2. Set the range switch at desired position
3. Connect test leads across the resistor to be measured and read LCD display.
4. If the resistor was being measured is connected to a circuit .turn off power and discharges all capacitors before applying test leads.

Diode test

1. Set the function switch at Ω position .(note: the polarity of red lead is positive “+”)
2. Set the range switch at \rightarrow position.
3. Connect the red test lead to the anode of the diode to be tested and the black lead to the cathode of the diode.
4. The approx. forward voltage drop of the diode will be displayed in mv.if the connection is reversed. Only figure “1”will be shown

Audible continuity test

1. Set the function switch at Ω position.
2. Set the range at \rightarrow position.
3. Connect test leads to two points of the circuit to be tested. if the resistance is less than 50Ω . Buzzer will sound.

Battery & Fuse Replacement

If the sign  appears on the LCD display .it indicates that the battery should be replaced. Remove the screw on the back cover and open the case .replace the exhausted battery with a new one of the same type.

Fuse rarely need replacement and blow almost always as a result of operator's error. open the case and replace the blown fuse with the ratings specified: F 200mA H 600V.

WARNING

To avoid electric shock, make sure the probes are disconnected from the measured circuit before removing the rear cover. Make sure the rear cover is tightly screwed before using the instrument.

Accessories

Battery	1pcs (12V GP-23A)
Carrying Case	1pcs
Operating manual	1pcs



00-05-4334